



The fasteners must penetrate a minimum of 3/4" into dimensional wood lumber.

Drawing shown depicts the application of all tile profiles. Unless otherwise noted it would apply to either concrete or clay tiles.

See Table 1A for additional fastening instructions.